


VOLUME

BALANCE


FUNCTION




OUTPUT

— TAPE —
REC PLAY

— INPUT —
AUX TUNER PHONO




1974-8 380



1974-7 375

1974-8 379

VRx8



1974-7 375

1974-8 379